

Zero Gravity Cordless Shade Installation

1. Install brackets by normal means per instructions included.
Note: CD100 and CD120 cassettes must be installed into mounting brackets prior to installing shade into the cassette.
2. Remove blue clip just prior to final install of shade.



3. Remove paper wrap which holds shade band around tube.
4. Place shade into bracket clutch end first, locking button will be depressed which will release the pre-tension.
Note: Make certain 2 to 3 inches of shade band hanging below tube before releasing shade.

5. Check tension of shade by pulling down and raising back up. If shade does not stay down or does not pull up properly adjustments can be made at this point. **Shade must remain in bracket to adjust tension.**
 - a. If shade will not stay down then too much pre-tension applied. Take shade band up to top, relieve 1 turn of tension by continuing to roll tube in same direction as raising shade. Bottom bar will come over back of tube and back into position. Test again and repeat if necessary.
 - b. If shade will not go up then either pre-tension lost by depressing locking button while not in bracket or insufficient amount applied. Take shade band up to top, hold bottom bar against tube and add 1 turn of tension by rolling tube in same direction as lowering shade. Bottom bar will travel over front of tube and back into position. Test again and repeat if necessary.
6. Complete install of fascia if required per instructions.
7. To operate shade hold at bottom and move up or down, release once in desired position and shade should stay in place. **Do not release shade while moving into position.**