


Simple Touch Remote Top Down Bottom Up Exploded View



1	PLP309	Alu. Head Rail PL ₃ (12"/pc) (Colored)	13	PLP307	Rail Insert PL ₃ (Plastic in Coil)
2	PLP311RN	Head Rail End Cap (Right) PL ₃ (Colored)	14	PLP327R	Alu. Middle Rail PL ₃ (12"/pc) (Colored)
3	PLP311LN	Head Rail End Cap (Left) PL ₃ (Colored)	15	PLP317	Mid. Rail End Cap PL ₃ (Colored)
4	STP029	Motor ST	16	PLP1011	Fix Button PL ₁ (Plastic)
5	STP030	Remote Control ST	17	PLP310	Alu. Bottom Rail PL ₃ (12"/pc) (Colored)
6	2232152	Screw for Head Rail (Zinc Plated)	18	PLP314N	Bottom Rail End Cap PL ₃ (Colored)
7	STP002	Battery Box ST	19	PLP107P	Weights With Double Face Tape PL ₁ (4"/PC),(8"/PC),(12"/PC)
8	STP005W2A	Power Adaptor ST	20	PLP118S	Eyelet PL ₁
9	STP031	Cordless Module Housing ST (Without Spring)	21	VBP2020	Tilter Rod End Washer 2T ₂ (Stainless)
10	VBP2015	Tilter Rod 2T ₂ (11.48"/pc) (Zinc Plated)	22	ZBP011	Supporting Rod ZB (Plastic)
11	PLP312RN	Mounting Bracket PL ₃ (Zinc Plated)	23	PLP121	Eyelet PL ₁
12	2233022	Screw for Mounting Bracket (Zinc Plated)			